

LEVEL THIS TOP LINE

CABINET TEMPLATE

Cut the opening
1/2" out beyond
these lines to allow
the Perpetual Well
to seat flush to
your cabinet

DO
NOT

DO
NOT

CUT
HERE

CUT
HERE

Drill 1/8" pilot
holes on each "X"
mark

